

INDASH by PANAVISE®

I-75102-607

Page 1 of 1

MOUNTING LOCATION:

Right side of radio

TOOLS REQUIRED:

- 8mm nut driver
- (4) Radio removal tools (DIN)
- Clean shop rag

HARDWARE INCLUDED:

None

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: **75102-607**
MFG: **AUDI**
MODELS & YEARS:
**A3 2006-07, A4 2002-2007,
S4 2004-2007, A4 Cabrio 03-2006**

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

- STEP #1** With the Audi Radio removal tools (Double DIN A4 -4 each), (Single DIN A3 -2 each) remove the radio and place it on the rag over the console. **DO NOT** disconnect the wires from the radio.
- STEP #2** With the 8mm nut driver, remove one screw from the right top corner of the radio cavity. Place the hole of the InDash Mount over the screw hole, align the holes and reinstall the screw. Carefully install the radio back into place.
- STEP #3** Attach the phone holder to your InDash Mount.

INSTALLATION IS NOW COMPLETE.
ENJOY YOUR NEW PANAVISE INDASH MOUNT.

A4 Screw Location



A3 Screw Location



A4 Final Install Picture



A3 Final Install Picture



08-17-06

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise InDash Applications List: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com © 2002 PanaVise Products, Inc