

MOUNTING LOCATION:

Right side of radio JR

TOOLS REQUIRED:

Phillips screwdriver

T-20 Torx driver

T-40 Torx driver

HARDWARE INCLUDED:

None

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: **75146-102**

MFG: **MINI**

MODELS & YEARS:

Cooper 2002-2004

CooperS 2002-2004

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With Phillips screwdriver, remove (2) screws from inside the cup holder, and set aside. With your hands pull up on the ring surrounding the shifter (6speed). Put your fingers in under the mirror control switch and push up. This will expose (2) screws. Remove these (2) screws and set aside.

STEP #2: Again with your hands and hook tool if necessary remove the knee panel on the drivers side, by starting at the top right side, pulling to release (2) clips. Tilt it out and pull to remove. Set panel aside.

STEP #3: With T-40 Torx driver, remove the (2) large screws on the left side pillar. Open the glove box door and remove the (2) T-40 Torx screws on the right side pillar.

STEP #4: Slide the shifter console towards the emergency brake, tilting the (2) pillars. Move the right side pillar to expose the screws on the right side of the radio.

STEP #5: With the T-20 Torx driver, remove the (2) screws on the right side of the Place the InDash by PanaVise Mount over the screw holes and reinstall the screws. Reassemble the dash in reverse order.



Shifter bezel lifted off, and shifting of pillars to expose mounting screws.

INSTALLATION IS NOW COMPLETE.
ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Final Install Picture



11-24-03